


For more visual information, take a look on our website to find building process video's and decorative idea's :-).




1A is for the hanging version  
1B is for the wall version +  
planter/desk version


5

Wiggle a bit with part 8 in order to get some room to install the wings. The side with the engraved lines should face down. The wings only have to be bend a little bit.

only a little bit!



carefully wiggle part 8 a little bit to get enough space to insert the wings.



The brown lasercut cardboard tends to make your hands a little dirty so it would be best to wash your hands after assembling the brown cardboard parts. This will prevent stains on the white cardboard and the paper wings.



Bend the tail a little bit with the engraved side facing down. Slide it under part 9, in the same gap.



If you like to make the bird as a hanger, you could use a simple cord to do the job. A thin yarn or thread. Tie a knot and hang the bird under a hanging lamp, wall shelf, hanging planter, small hook in your ceiling and so on. Also very nice to make more birds and build your own mobile! :-)



# King Fisher Paper birds


Instructions. Please read before you go for it :-)

**!** Important: The cardboard and paper parts are fragile so please assemble carefully. Don't squeeze or press hard on the parts for best final result. The lasercut brown cardboard tends to make your hands a bit dirty so it would be best to wash your hands after assembling the brown cardboard parts. This will prevent staining the white cardboard and the paper wings.


Note for the paper wings. Bend them just a little bit with the engraved lines facing down in order to bow the part gently.

lets go! Time to decide if you want your bird as a hanger or bird on the wall or the wooden stick. For the hanging version, use part 1A instead of 1B. If you like to make the bird on a stick for a planter or vase, use 1B and skip step 1+2+3.

1




2




Insert the stick carefully by gently rotate & push it starting from the bottom. Hold the E parts with your fingers to prevent bending. Let the pointy side stick out 8 cm or any other length you prefer.

3




Cut off the length sticking out of the bottom that you don't need. Use a plier or knife. In case of using a knife, remove the stick, place it on top of a cutting board. Gently push and roll the stick over the board. Now you can make a clean break.


craft cardboard



white cardboard



gradient offset printed paper



white cardboard

